

# STEEL WOOL RECOVERY BUCKET INSTRUCTIONS

(Item #s: SW3G, SW3P, SW5G, SW5P)

1. Prefill the Steel Wool Bucket with water to prevent “channeling” and increase the life span of the bucket.
2. Locate the Steel Wool Bucket close to the processor or gravity feed system and the drain. Make sure the processor or holding tank system overflow outlet is higher than the inlet of the Steel Wool Bucket.
3. Screw the included black threaded fittings clockwise into the inlet and outlet spin welds on the bucket.
4. Connect ¾”ID tubing from the processor or batch system to the Steel Wool Bucket INLET port, located on the left side of the front of the bucket. (The label includes arrows showing the inlet/outlet)
5. Connect ¾” ID tubing from the Steel Wool Bucket OUTLET to the drain or alternate waste containment unit.

To avoid potential back ups into the processor tank, inspect and clean the hosing on a regular basis. To prevent air locks, loosen the vent port lid on the top of the bucket.

## PROPER DISPOSAL/REFINING OF USED RECOVERY BUCKETS

1. All liquid **must be drained** from the unit prior to shipping or the units MUST be shipped as a hazardous waste. To Drain the units, decant the liquid from the used bucket into the new bucket being installed.
2. For EPA Compliant Disposal Services, please send drained buckets using the carrier of your choice to: **Nohcor Disposal Services**, 5 Commerce Dr., Aston, PA 19014. Buckets are properly disposed of at no fee.
3. For Refining Services, please send drained units using the carrier of your choice to: **Nohcor Refining Services**, 5 Commerce Dr., Aston, PA 19014. A minimum refining fee of \$125 or 40%, whichever is greater, will be charged. Settlements of more than \$125 will be issued a check. Settlements of less than \$125 will be issued an invoice, payable on receipt.

Please keep your tracking number as this is proof of proper disposal/refining services.

**Product Proudly Manufactured by a small business in the USA:**

**NOHCOR LLC**

**W1780 AUBURN ASHFORD DRIVE, CAMPBELLSPORT, WI 53010**

**Email: [m.nohcor@gmail.com](mailto:m.nohcor@gmail.com), Phone: 262-483-4806**